



Parts List

- A. Custom Acrylic Panel (x1)
- B. Plastic Standoff (x4)
- C. Standoff Barrel (x4)
- D. Screw (x4)

Tools Required: Drill, Pencil



Scan the QR
code to visit the
product page.

Mounting Instructions

1. Place the acrylic panel in the desired position on the cashwrap and mark the 4 standoff locations using a pencil.
2. Place a screw into each standoff barrel. Drill the standoff barrels to the surface at the marked locations.
3. Press a plastic standoff into each barrel and remove the paper from the adhesive pads.
4. Place the acrylic panel onto standoffs. Press firmly over the adhesive pads to secure.

