

- 3. Match the holes of the flange and the bottom profile and spin the wing nuts
- 4. Finally, install the printed textiles to the front and the back. Then, plug in the electric cable.







Scan QR code to visit the product page