



## Installation Instructions

1. Hold one of the clear acrylic panels in the desired location on the surface that you wish to attach the panel. With a pencil, trace the holes in the panels onto the surface you are mounting the panels. Mark the center of each circle.
2. Set aside the panel. Using a power drill and a 1/16" bit, drill a pilot hole into the center of each circle you traced from the panel.
3. Then, in each pilot hole, screw in the threaded flange base of the stand-offs.
4. Now you can attach the base of the stand-offs to the threaded flange bases you just attached.
5. Sandwich the Ava Elisabeth graphic between the two clear acrylic panels, making sure all the holes are aligned.
6. Using the stand-off caps, secure the panels to the bases of the stand-offs.

