CMB Sign Stand With Literature Pocket Assembly Instructions



Step 2: Screw sign holder brace into the top of the post. Step 3: Open top and bottom of snap frame and secure to top of sign holder brace using screws.

Step 4:

Attach literature pocket to the back of snap frame and brace. Secure using black screws through front of frame. Fasten with tightly with nuts on posterior side of literature pocket.



