

## CNTRTRS3X Assembly Instruction

Step 1. Open a Truss section① and align screws with holes on Base②. Rotate Truss section① clockwise. Make one full turn on one truss tube and repeat on next tube. Continue to alternate turning all truss tubes to ensure base does not bind. Tighten all four truss connectors.

Step 2. Assemble the Middle Top③ to the two truss by rotating the Rotate Tube④, the procedure is the same as the fasten using in Step 1.

Step 3. Assemble the Side Top⑤ to the truss, the same procedure as Step 2.

!!!Warn: Please release the hinge when disassemble the tops

