

FLROV36 Assembly Instruction

1. Screw poles onto top frame(fig-A).
2. Screw frame onto base(fig-B).
3. Insert graphics between mid backer and lens on front and back of display(fig-C).

