


**SMAEWDMD - Acrylic Eyewear Rack**

Step 1. Slide the Back Panel (A) downward onto the Front Panel (B) as shown. Snap the tab into the cutout to lock the Back Panel in place.

Step 2. Test the stability of the rack and make sure the back panel is completely inserted. The assembly is finished.



Scan QR code to visit the product page:

