

# PARTS LIST - 1



AGCON2  
(x4)



AGCON1  
(x4)



DRAWER LOCK (x2)



HW117 - T2 (x1)



SIDE GLASS (x2)



#6x12 PHILLIP  
SCREW (x34)



1/8" SCREW (x70)



SQUIP (x1)



HW116 - T1 (x1)



SHELF GLASS (x2)



FL x 1/4\"/>



#6x10 PHILLIP SCREW  
(x4)



BTSC  
(x6)



HW18 - T1 (x1)



GLASS DOOR (x2)



NEOSHA-26 (x2)



GLASS GUIDE (x6)



DOWEL PIN  
(x12)



TOP GUIDE  
(x6)



GUIDE  
(x70)



SS2TCD  
(x1)



DOOR PROTECTION (x2)



SHELF SUPPORT  
PIN (x16)



PLASTIC GLAZING  
(x6)



BOLT  
(x64)



#16 CAM LOCK  
(x4)



COUNTER  
SLIDERS  
(2 PAIR)



DRAWER  
SLIDERS  
(2 PAIR)



SCREW/CAP  
(x38)



SCREW/CAP (x6)



BOOKEND



CAP (x2)

TOOLS NEEDED



1.

**BASE AND SIDE ASSEMBLE**

BOTTOM PANEL (x1)  
TOE KICK PANEL (x3)  
RIGHT SIDE PANEL (x1)  
#10 CAM LOCK (x22)

BOLT (x28)  
COUNTER SLIDER (x1)  
#6x12 PHILLIPS SCREWS (x2)

1. Connect toe kick panel to bottom panel using bolts.
2. Insert and tighten #10 cam locks.
3. Attach slider to the left panel with #6x12 phillips screws.
4. Connect base with right side panel using bolts.
5. Insert and tighten #10 cam locks.
6. Insert the bolts on bottom panel.



2.

**CENTER PANEL & FRONT PANEL ASSEMBLE**

CENTER PANEL (x2) BOLT (x2)  
FRONT PANEL (x1) COUNTER SLIDER (x2)  
#10 CAM LOCK (x18) #6x12 PHILLIPS SCREWS (x4)

1. Attach slider to center panels tightly.
2. Connect the front and bottom panels tightly.
3. Attach center panels to bottom base tightly.



3.

## LEDGE TOP ASSEMBLE

LEDGE TOP PANEL (x1)  
LEDGE TOP FRONT PANEL (x1)  
DIVIDED PANEL (x1)  
#10 CAM LOCK (x16)  
BOLT (x4)

1. Connect ledge top front panel and ledge top panel : tighten.
2. Insert #10 cam lock in divided panel.
3. Connect divided panel to ledge top panel : tighten.



4.

## TOP PANEL ASSEMBLE

TOP PANEL (x1)  
#10 CAM LOCK (x4)  
BOLT (x16)

1. Attach top panel using bolts.
2. Tighten #10 cam locks.
3. Connect ledge top with top panel : tighten.



5.

**LEFT SIDE PANEL ASSEMBLE****LEFT SIDE PANEL (x1)****BOLT (x16)****COUNTER SLIDER (x1)****#6x12 PHILLIPS SCREWS (x2)****GUIDE (x1)****SCREW CAP (x34)****WHITE SCREW CAP (x6)**

1. Attach slider to the left panel with

#6x12 phillips screws.

2. Attach left side panel using bolts.

3. Tighten #10 cam locks.

4. Secure all the #10 cam lock/shelf cover caps.

5. Attach guides on the top shelf.



6.

**DRAWER ASSEMBLE****DRAWER FRONT (x2)****DRAWER RIGHT (x2)****DRAWER LEFT (x2)****DRAWER BOTTOM (x2)****DRAWER BACK (x2)****DRAWER SLIDERS (2 PAIR)****#10 CAM LOCKS (x4)****BOLT (x4)****DOWEL PINS (x12)****#10 SCREW CAPS (x4)****DRAWER LOCK & KEY (x2)****#6x12 PHILLIPS SCREWS (x24)****#6x118 PHILLIPS SCREWS (x4)**

1. Insert dowel pins into place.

2. Connect drawer left, drawer right, and drawer back pieces.

3. Slide in drawer bottom.

4. Attach drawer front to drawer using bolts; tighten #10 cam locks.

5. Secure the drawer side slatback using #6x118 phillips screws.

6. Install the drawer lock using #6x12 phillips screws.

7. Attach drawer sliders to drawer using #6x12 phillips screws.

8. Install #10 screw caps.



7.

## INSTALL DRAWER & SHELVES

SHELF SUPPORT PINS (x16)

SHELF PANEL (x2)

CENTER SHELF PANEL (x2)

CAP (x1)

1. Insert shelf support pins in place.

2. Slide drawer and shelf into place.

3. Insert cap into hole.



8.

## STANDARD&DOOR FRAME ASSEMBLE

#6 x 58 PAN SCREW (x11)

HW117-71 (x1)

SS27CD (x3)

1. Attach HW17-71 on top, tighten by using 2 #6x58 pan screw

2. Tighten SS27CD on third panel with 1 #6x58 pan screw.

3. Tighten the same SS27CD part on base with 2 #6x58 pan screws

3. Repeat steps 1 & 2 to assemble the other 2 pcs of SS27CD.



9.

**SIDE GLASS ASSEMBLY**

SIDE GLASS (x2)

AGCON 2 (x4)


AGCON 3 (x4)

#6X58 PAN SCREW (x12)

PLASTIC GLAZING (x8)

TROX SCREW 3/4" (x8)

1. Connect right side glass with bottom and front panel using AGCON 2 & AGCON 3 using 8 TROX SCREW 3/4" & #6X58 PAN SCREW.
2. Repeat step 1 to connect left.
3. Put plastic glazing on TROX SCREW 3/4".



10.


**DOOR FRAME ASSEMBLY**

#6 x 58 PAN SCREW (x2)

HWR16-T1 (x1)

HWR18-T1 (x1)

1. Attach HWR16-T1 to bottom panel using #6x58 pan screws.
2. Snap HWR18-T1 into HWR16-T1.



c

11.

**BRACKET AND GLASS SHELF ASSEMBLE**

BT12C (x4)

GLASS SHELF (x2)

1. Attach BT08C to SS27CD with proper height.
2. Place glass shelf sit on brackets.



12.

**GLASS DOOR ASSEMBLE**

GLASS DOOR (x2)

GLAZING CHANNEL (x4)

NE09034-4 (x2)

TOP GUIDE (x4)

#W12 PHILIPS SCREW (x2)

DOOR PULL (x2)

LOCK (x1)

DOOR PROTECTION (x2)

1. Put 2 pcs of glazing channel on glass door.
2. Install NE09034-4 door protection with glass door.
3. Install lock with NE09034-56 by #W12 Philips screw.
4. Put 2 pcs of top guide on the top of glass door.
5. Insert glass door into case.
6. Attach the DOOR PULL on glass door.
7. Repeat 1-6 to install other glass door.

