

Instruction

Parts:



Assembly:

Step 1 Connect the sectioned pole together



Step 2 Install the base



Step 3 Install the pole to the base



Step 4 Install the pole to the pocket panel



Done!

