QCRND Series Sign Holders

Parts List & Assembly Instructions

Step 1:

Please read all directions before assembling

Step 2:

Check that all parts are included Parts List

- (1) Quick-Clip Sign Holder/Pole Assembly
- (1) Heavy Metal Base
- (2) M6 x 0.75 Allen Head Screws for Base
- (1) Hex Key for above
- (1) Two-Screw Channel Plate (in poly bag) for attaching Pocket
- (1) Clear Acrylic Pocket (included with QCRND8511 & QCRND1117)

Step 3: (Only applies to versions with pockets) **Installing Two-Screw Channel Plate** on QCRND8511 (with pocket) only

Before attaching base, remove two-screw channel plate from poly bag. Slide channel plate with screws into the channel on the pole assembly from bottom. Tip: Lay unit on floor with channel facing up, adjust the position of plate by sliding it within channel to the desired pocket height. Remove screws with a Philips-head screw driver (not included).

Step 4: (Only applies to versions with pockets) Attach Clear Acrylic Pocket to Pole Assembly


Place clear acrylic pocket over plate lining up holes. Reinsert screws through pocket into plate and tighten (see illustration). Note: Tighten screws carefully when attaching pocket. Over-tightening may crack the acrylic. Tighten only to snug. Do not over-tighten.

Step 5:

Attach Base to Pole/Sign Holder Assembly

Stand base along edge and line up pre-threaded holes in pole assembly. Place two screws through base into threaded holes located in bottom of pole assembly. Fasten screws with provided hex key. Note: Pole assembly is aluminum - do not over tighten hex screws.

Questions? Call 1-800-572-2194.



DIVISION OF GEORGE PATTON ASSOCIATES, INC.