

RBWC8511 & RBWC57

ASSEMBLY INSTRUCTIONS

1. FOLD UP LEFT AND RIGHT SIDES
2. FOLD OVER BACK INTO SIDE AND INSERT TAB INTO SLOT
3. FOLD IN BOTTOM FLAP A FIRST ALONG WITH B&C
4. SNAP IN BOTTOM FLAP D UNDER BOTTOM A
5. FOLD IN TOP SIDE TABS AND CLOSE TOP
6. INSERT HEADER INTO SLOT ON TOP OF UNIT

