















**Step 6:** Secure the Header Plate (F) to the top of each Pole Set. Pass a Machine Screw (H3) thru each thru hole in the Header Plate and into the top of each Pole Set.



