

# TOTM Stand How To Guide

---



Align top and base pieces by putting the top near the upward facing arrow.



Insert black screws into the bottom base with large Allen wrench.



Insert silver screws into the top piece with small Allen wrench.



Insert 58 W fluorescent bulb light.



Slide PVC backing into the intended grooves.



Screw the clear lens into holes on the inside of the open snap frame. Make sure the arrow is pointing towards the top of the display and is on the inside of the lens.



Lift the clamp with your thumb and slide the poster underneath.



Snap the frame shut.



Place the poster underneath the second clamp.



Snap the second frame into place.



Your snap frame display setup is now complete!