TWN Poster Holder Series Assembly Instructions

Components:

- a. (2) Hex Screws
- b. (4) Levelers
- c. (1) Frame
- d. (1) Square Base
- e. (1) Allen key

Step 1:

Screw all four levelers (b) into four corner openings of the bottom of the square base (d).

Step 2:

Lay the frame (c) on its side and position square base (d) against it, aligning the remaining square base openings with the frame's legs. Using Allen key (e), screw the two hex screws (a) through the bottom of the base and into the frame.

Step 3:

Once the frame is secured on the square base, position stand upright. Insert graphics using the side insert.

DISPLAYS2GO



