

Assembly Instructions

UVCPTR42

DISPLAYS2GO

1

Bend the body of Bollard Sign at the precut lines to create triangle shape, and line up tabs with slots.



Referenced Parts

Tab



2

Insert tab into slot and use slight pressure to press the tab into the slot making sure it is fully inserted.



Slot



3

Repeat this process for the remaining tabs and slots.