

Installation Instructions

1. Hold the clear acrylic panel in the desired location on the surface that you wish to attach the panel. With a pencil, trace the holes in the panel onto the surface you are mounting the panel. Mark the center of each circle.
2. Set aside the panel. Using a power drill and a 1/16" bit, drill a pilot hole into the center of each circle you traced from the panel.
3. Then, in each hole, screw in the base of the stand-offs.
4. Using the stand-off caps, secure the panels to the bases of the stand-offs.

