

8.5 X 11" CEILING SIGN HOLDERS WITH 16-FOOT STEEL CABLE SYSTEM

Assembly Instructions

SKU: Landscape 1CAB1185X1, 2CAB1185X1

SKU: Portrait 1CAB8511X1 2CAB8511X1,
3CAB8511X1 4CAB8511X1



Scan the QR code to
visit the product page.



Safety & Warnings


BEFORE BEGINNING ASSEMBLY, PLEASE TAKE TIME TO READ THROUGH THE INSTRUCTIONS AND UNDERSTAND EACH STEP THOROUGHLY.

Displays2go is not responsible for any personal injury or product damage due to mishandling, incorrect mounting, incorrect assembly or incorrect use of this product.

Components




A. Cable, 16ft (x2 rolls)



B. Acrylic Panel (x1) *



C. Hex Set Screws, Long (x6) *
Hex Set Screws, Short (x4) *




D. Ceiling Mount (x2)



E. Panel Gripper (x2)



F. Hex Wrench (x2)



G. Connector (x2) *



H. Mounting Hardware Bag x1



*Quantities listed are per frame and depend on the total number of acrylic sign holders.

Assembly


Mount to Ceiling

⚠ The most important part of the cable system is how it is mounted. The cable system must be secure and be able to support the weight of the assembly. Make sure you fully understand the steps necessary for installing the cable system. Displays2go is not responsible for incorrect installation or use of the product.




1. Determine the location for unit and the material of the ceiling. Mark location for each ceiling mount, keeping the appropriate distance between the mounts, shown below.

Portrait





Landscape




2. Unscrew the plug from the ceiling mount using the hex wrench or other tool.



3. Install the ceiling mount to the ceiling, following the appropriate procedure for your ceiling material. See examples below of ceiling types and their required mechanical fasteners.




4. Insert the end of the cable into the ceiling mount, and secure in place using a short set screw and hex wrench.
5. Repeat on other ceiling mount.



6. Determine the length of the cable from the ceiling mount to the top of the first acrylic panel. Once marked and measured, cut both cables to the same length.

Attach Panel Grippers

7. Place a panel gripper at the end of the cord and secure using a short set screw.
8. Peel the film from the acrylic panel and insert the overhanging edge into the slot of the panel gripper.
9. Secure the panel in the panel gripper with a long set screw.
10. Repeat on second cable, keeping the panel even on both cables.



Attach Connectors

11. Place a connector onto the bottom edge of the acrylic panel. Secure with a long set screw.
12. Attach the second connector on the other side of the panel.
13. Place the next acrylic panel into the bottom set of connector notches and secure using long set screws. Connect additional panels as needed.



Assembly is complete.

If you have any questions regarding our products, please visit us at www.displays2go.com or contact Displays2go customer service at 844-221-3388.