

37" Glass Clothing Display Case with Rail and Internal Lights

37LEDCDWH (Glass Clothing Display Case)

Version 1.0



Safety Information

- Please read and understand all instructions before beginning assembly.
- 2 people are required for safe assembly; 3 people are recommended.
- Handle all glass components with caution.

Components

Parts

- | | |
|--------------------|---------------------|
| A. Base (x1) | D. Case Top (x1) |
| B. Back Panel (x1) | E. Glass Shelf (x1) |
| C. Side Panel (x2) | |


Hardware

- | | |
|--------------------------|-----------------------|
| F. Corner Connector (x4) | J. Top Connector (x2) |
| G. Screw (x16) | K. Top Screw (x2) |
| H. Washer (x14) | L. Shelf Peg (x4) |
| I. Rubber Washer (x16) | M. Peg Washer (x4) |

Assembly


Step 1: Prepare for Assembly.

1. Prepare a soft place for assembly to prevent damage to the glass panels.
2. Unpack the **Base (A)** and the hardware.
3. Unpack and identify all glass panels.




Step 2: Install Back and Side Panels.

1. Insert the **Back Panel (B)** into the back channel of the base. Refer to the pre-drilled holes shown in the diagram to determine the panel orientation.
2. While holding the Back Panel in place, insert a **Side Panel (C)** into the base side channel, noting the correct panel orientation (see diagram).
3. Connect the glass panels using **Corner Connectors (F)** at the locations shown.
 - Use a **Washer (H)** on the screw outside of the glass.
 - Place 2 **Rubber Washers (I)** on the screw inside of the glass, then screw into Connectors.
4. Repeat for the other **Side Panel (C)**.




Step 3: Install the Top of the Case.

1. Place the **Case Top (D)** and connect with 2 **Top Connectors (J)**.
 - Insert a **Top Screw (K)** down through the Case Top into the Top Connector.
 - Screw through the glass panel using washers to secure the other side of the Top Connector.
2. Repeat on the other side of the case top.



Step 4: Install the Glass Shelf.

1. Install the 4 **Shelf Pegs (L)** using a washer and a peg and a **Shelf Peg Washer (M)**.
2. Place the **Glass Shelf (E)** onto the pegs.



Step 5: Illuminate the Display Case.

1. Plug in the power cord to turn on the lights.
2. Flip the power cord switch ON.

Assembly is complete.

