

ASSEMBLY INSTRUCTIONS


ACEASFLHFR - Floor Acrylic Easel H Frame


DISPLAYS2GO

V19.09

 Socket Screws M5X15 6 pcs

 Wing Screws M5X10 4 pcs


 Allen key 1 pc



Scan QR code to visit
the product page:




If you have any questions regarding our products,
please visit us at www.displays2go.com or contact
D2G customer service at 844-221-3388.



STEP 1

Assemble the easel body, base and supporting legs by using M5X15 screws, as shown above.



STEP 2

Assemble the brackets onto both side of the easel body with M5X10 screws. Adjust the brackets to desired position.