

ASSEMBLY INSTRUCTIONS

DISPLAYS2GO

ACEASFLSGN - Floor Acrylic Easel with Poster Holder

V19.09

Scan QR code to visit the product page:




Wing Screw M4X40 1 pc




Wing Nut M4 1 pc

If you have any questions regarding our products, please visit us at www.displays2go.com or contact D2G customer service at 844-221-3388.



STEP 1

Assemble easel and support leg with M4X40 screw and M4 nut. Tighten them by hand to secure the acrylic easel.



STEP 2

The assembly is finished.