




Bamboo Retractable Banner Stand

Assembly Instructions

SKUs: BBRBST3382, BBRBST3335, RCBN3382CP, RCBN3382CP

Parts:



Assembly:

Step 1. Remove everything from the box and carrying bag and make sure all parts are present.

Step 2. Open the endcap of the Top Rail, push the Banner Rod inward and slide it out.



Step 3. Remove the backing of the adhesive strip on the Banner Rod and attach it to the top of your banner, make sure your banner wrapped the Rod twice. And then return it back to the inside of the Top Rail.



Step 4. Remove the adhesive backing on the leader coming out of the base. Tape the bottom of your banner to the leader.



Step 5. While holding the top of your banner securely, remove the pin from the side of the base. **Do not pull the pin out until your banner is completely installed.** This is what gives your banner tension, and once you pull the pin out there is no way to re-tension your banner stand. Slowly guide the banner into the base.



Step 6. Take the pole that is broken down into 3 sections and attach them together. Insert the pole into the hole in the back of the base. Raise the banner and attach it to the top of the pole



If you have any questions regarding our products, please visit us at www.displays2go.com or contact D2G customer service at 844-221-3388.