


SKU: DIGCOM43



DIGITAL ART FRAME EASEL - 43"

Assembly Instructions





DISPLAYS2GO

CONNECTING PEOPLE & BRANDS WITH THE WORLD




Letter represents the hardware. Number is equal to the quantity of each part.





1. Install the body of the easel and connect the horizontal and vertical rods with screws.

2. Check the front and back side of the body of the easel to ensure that it is properly installed. Compare against the image above.



3. Connect the vertical bar to the tray and install the latch, as pictured.

4. Assemble the tray by attaching to the body of the easel. Height of the easel can be adjusted by sliding the tray.



5. Assemble the base frame and the wheels by screwing together. Holes are pre-drilled.

6. Connect the body of the easel with the base with screws. Then attach the support bars, which can be used to adjust the tilt angle.



7. Install the fixing tray and lock it, as shown.




Scan QR code to visit product page.


How to Adjust Height and Tilt Angle of Easel



Adjust tilt angle by sliding the screws.



Adjust height of easel by sliding the latch.



If you have any questions regarding our products, please visit us at www.displays2go.com or contact D2G customer service at 844-221-3388.