


10' LED-Lit Fabric SEG Backwall

SKU: 10SEGBCKWALL




Packing List:

- A. Outer Frame Components (10 pcs)
- B. Inner Frame Poles (6pcs)
- C. Inner Frame 4-Way Connectors (2pcs)
- D. Feet (2pcs)
- E. LED Power Inputs (2pcs)
- F. Power Adaptor (1pc)
- G. Power Cable (1pc)
- H. Custom Printed Fabric Banner (1pc)
- I. Travel Case (1pc)


Note: 2 people recommended for assembly.

Assembly

1. Arrange all components of the outer frame on the ground, matching shapes on stickers of each piece (see diagram below).
2. Connect all pieces of the bottom, left, and right sides of the outer frame.




3. Assemble inner support frame poles, placing the white plastic tips into the corresponding slots of the outer frame. Connect vertical and horizontal poles using 4-way connectors.




Note: Vertical poles are slightly wider than horizontal poles. Orient the 4-way connectors so poles fit securely.

4. Connect top frame components to the rest of the outer frame, matching shapes on stickers of each piece.




5. Tilt the outer frame slightly upward and slide the tabs of metal foot through the outside slots of the outer frame. Once in place, rotate each tab and press the tab down to lock the foot in place. Repeat for other foot.



6. Unfold and arrange SEG fabric graphic. To insert, fold the plastic strip to a 90° angle and insert into front channel of frame. Start at the corners and press the strip in, working towards the center until graphic is firmly installed.



7. Carefully lift unit to standing position.
8. Plug both white LED power inputs into ports on lower right of outer frame. Plug the other side into the power adaptor. Plug the cord into the power adaptor and insert into outlet to turn on LED lights.



Assembly is complete.

Note: Refer to printed diagram inside travel case to repack unit components.