

Ballot Box Assembly Instructions

SKU: FDHDBBP1





DISPLAYS2GO
CONNECTING PEOPLE & BRANDS WITH THE WORLD

List NO:	D: 2pcs	E: 2pcs	F: 4pcs	G: 4pcs	H: 4pcs	I: 2pcs	2pcs
Photo		 Large washers					

- Ⓐ Box Assembly
- Ⓑ pole
- Ⓒ Base



Scan QR code to visit product page



If you have any questions regarding our products, please visit us at www.displays2go.com or contact D2G customer service at 844-221-3388.