

Poster Stand Base with Adjustable Clamp

SKU: FLRHLD24, FLRHLD24BK [V2.0]



DISPLAYS2GO
CONNECTING PEOPLE & BRANDS WITH THE WORLD

Assembly

Included: Stand Base (Left x1, Right x1), Screws (x3), Washers (x3), Wingnuts (x3), Wrench (x1)

1. Place left and right base pieces on either side of your poster.
Position your poster to be centered and flat against the bottom of the base.
2. Create holes in your poster to align with base screws.
Tip: Measure and mark screw locations on your poster using the measurements below. Or, place poster in base and tighten screws halfway to create indentations. Remove poster and add screw holes at indentations.
3. Attach base pieces and poster using screws, washers, and wingnuts. Tighten wingnuts until poster is secure in the base.





Diagram and measurements (inches)



If you have any questions regarding our products, please visit us at www.displays2go.com or contact Displays2go customer service at 844-221-3388.