

RGBW LED Light IR Remote Control

Instructions (V1.1)




(1) CR2025 Battery included.
Remove the plastic film before
using the remote control.

⚠ NOTE: Aim the remote control directly at the receiver!

The receiver's location varies by product. It can be found by following the power cord up to the underside or side of the unit.

Bring the remote within 12 inches of the receiver and aim the remote directly at the receiver window.

Avoid placing the receiver in strong direct sunlight. Remove any obstacles between the remote and the receiver.



RGB Light
Brightness

RGB Light ON/OFF

⚠ NOTE: Turn RGB lights
OFF for White Light only.

RGB Solid Color

White Light
Brightness

White Light ON/OFF

Preset Brightness Level

Color
Changing
Mode

Color Changing Speed

