



6-Shelf Bakery Cart Tray Display Instructions

Parts List:

- Right Side Frame (x1)
- Left Side Frame (x1)
- Top Frame Support (x1)
- Bottom Frame Support (x1)
- Wire Shelves (x6)
- Small Sign Holder (x1)
- Large Sign Holder (x1)
- Casters (x4)



Bakery Cart
w/ Small Sign




Bakery Cart
w/ Large Sign

Hardware:


Each unit should be supplied with (1) Phillips screwdriver, (1) hex key, and the following hardware below. The letter above each piece of hardware is referenced on the assembly diagram of Sheet 2.

A




Socket Cap Bolt
(x8)

B



M10 Flat Washer
(x8)

C



Spring Lock Washer
(x12)

D




Pan Head
Tapping Screw
(x2)

E



M4 Flat Washer
(x2)

6-Shelf Bakery Cart Tray Display Instructions



If you have any questions regarding our products, please visit us at www.displays2go.com or contact D2G customer service at 844-221-3388.