CLRTNTW10 - 9.5'W X 6.5'H Clear Tent Wall



1. Unroll the tent wall and find the hook and loop strip on top of the wall. Attach the hook and loop strips to the tent frame starting at the top corners.

Rev. 21.10

- 2. Secure the remaining hook and loop strips to the corresponding frame.
- 3. Fully expand the tent wall and attach each hook and loop to the tent leg as shown.



Care of Vinyl wall: When not in use, roll up the vinyl wall with the cardboard tube to avoid creasing.

If you have any questions regarding our products, please visit us at www.displays2go.com or contact D2g customer service at 844-221-3388.