
Loosen all the clamps and hold your POS device (not included) to the plate. Move the clamps to secure the device firmly.

Tighten all the screws on the back of the plate with the included Allen Wrench. Your Keypad extender is ready to use.



Scan QR code to visit the product page:



If you have any questions regarding our products, please visit us at www.displays2go.com or contact D2G customer service 844-221-3388.

REV. 21.01 1 of 2