









ASSEMBLY INSTRUCTIONS

DISPLAYS2GO

XSHF3BRN

V19.11

PARTS LIST

<p>A</p> 	<p>B</p> 	<p>C</p> 	<p>D</p> 
<p>SIDE FRAME ×2</p>	<p>BOTTOM ×1</p>	<p>MIDDLE&TOP SHELF ×2</p>	<p>SHORT SCREW ×4</p>
<p>E</p> 	<p>F</p> 	<p>G</p> 	<p>Scan QR code to visit the product page:</p> 
<p>LONG SCREW ×8</p>	<p>ALLEN WRENCH ×1</p>	<p>LEVELER FEET×4</p>	

Step 1. Screw Leveler Feet (G) to the Bottom Shelf. Attach Side Frames (A) to Bottom Shelf (B) using Allen Wrench (F) and 4 screws (D). Secure tightly.



Step 2. Place Middle Shelf (C) on the Frame and secure with 4 Long Screws (E).



Step 3. Place Top Shelf (C) on the Frame and secure with 4 Long Screws (E).



Step 4. The assembly is finished.



If you have any questions regarding our products, please visit us at www.displays2go.com or contact D2G customer service at 844-221-3388.