



DISPLAYS2GO
CONNECTING PEOPLE & BRANDS WITH THE WORLD



SKU: MWMCDC



SKU: MWM47DC



SKU: MWM39DC

MWM DISPLAY CASE SERIES

Care and Maintenance

Indoor Use:

Do NOT expose the product to the outdoor weather conditions. Cover product during outdoor transport. Avoid excess humidity.

Adjusting Shelves:

First, remove the 4 assembled shelf supports and insert them to the desired height. Carefully lift the shelf and, keeping it tilted, place it on the side supports, placing one of its two short sides first.

Cleaning:

To clean wood, wet a soft cloth or non-abrasive sponge with water, glass cleaner, or other neutral detergent and gently wipe unit. Do not use aggressive detergents such as degreasers or acids. Use a soft cloth with glass cleaner or alcohol to gently clean the glass.