

Installation Instructions

V21.11

OUTDOOR ADHESIVE WALL SIGNAGE

ODWC2418CP

ODWC3624CP

ODWC4836CP

ODWC5248CP

Surface Preparation:

- A. Prior to installation, make sure the surface is completely dry and free from water, grease, oil stains, acids, sand and pebbles. If the surface is not clean and dry, the adhesive performance will be inhibited.
- B. The material cannot be exposed to rain, snow, soap etc., for 24 Hours after the installation, as any exposure will inhibit adhesive performance.

Signage Application:

1. Initially apply the material by hand.

Tips: Using an applicator roller will help to ensure the material conforms to the surface it's been applied to.

2. Force all air out to ensure the material is completely adhered to the surface.
3. The printed signage works best when applied edge to edge without overlapping.

Pro Tips: Tap edges of material with a rubber mallet or use a roller to help with sealing the graphic to the surface.

NOTE: Not recommended for use on smooth painted interior surfaces as the removal of the graphic may damage the wall surface.

Cleaning:

To clean the signage, start at the center and work your way to the outside.

Removing:

Using a putty knife or razor, peel the signage off at less than 45°.

Tips: It's easier to remove the signage under warm conditions.

Scan QR code to visit
the product page:



If you have any questions regarding our products, please visit us at www.displays2go.com or contact D2G customer service 844-221-3388.

