



SKUs: ENCLTV5055, ENCLTV5765

OUTDOOR PROTECTIVE ENCLOSURE


User Manual

PARTS LIST



Scan QR code to visit product page

QUANTITY




PART A: Enclosure * B: Tempered Glass* D: Fan * E: Thermostat*.... G: Hardware (at right)1 H: Key2 1: Rubber Gaskets.....2 J: Rod*.....2 Expansion screw *: Arrives assembled NOTE: 2-3 person assembly Tools Required: Drill; Phillips



If you have any questions regarding our products, please visit us at www.displays2go.com or contact Displays2go customer service at 844-221-3388.


Head Screwdriver



1. Remove one of the bottom covers to pass cables for TV and fan through. Insert rubber gasket into hole.


NOTE: Wires for fan come attached to fan.

2. Remove bracket from the TV enclosure by unscrewing pre-attached bolts.



ATTACH BRACKET TO TV

- 3. Mount the the bracket arms to the back of the TV, using the M4/M6 screws.
- 4. Mount bracket to the arms by tightening all screws to attach.
 - 5. To hold unit door up, insert metal rod into hole. This is located along the hydraulic rods.



MOUNT ENCLOSURE TO WALL

- 6. Drill four 8mm holes into desired wall, being careful to measure for appropriate dimensions and level installation.
- 7. Put expansion screw caps into the holes.
- 8. Two people should hold the unit against the wall, while a third inserts and tightens expansion screws.

NOTE: Enclosure door may need to be held open while installing.

NOTE: Additional hard wire installation may be required by a licensed electrician. User may choose to utilize an outdoor rated power strip.

MOUNT TV TO ENCLOSURE

- 9. Two people lift the TV and carefully insert into the enclosure.
- 10. Fit bracket arms attached to the back of the TV onto the mounting bracket, which comes pre-installed inside the enclosure.
- 11. Reach under TV to tighten screw on bottom of the bracket, which will hold unit in place.
- 12. Slide cable through hole at the bottom of the enclosure.

INSTALLATION NOTES

TROUBLESHOOTING

If unit's fans do not work, check for the following:

- No Power | Solution: Connect to power supply
- Temperature Too Hot/Cold | Solution: Set thermostat to proper temperature (~77 °F)

ENVIRONMENT

- Wall should be flat and able to bear the weight of the unit.
- Keep away from heat sources and direct sunlight.
- Fans on unit can be turned on to help circulate air. Power switch is on inside top of unit.

SPECIFICATIONS

| Voltage | 110/220 V |
|---------------------|--|
| Rated Power | 60W |
| Working Temperature | 14 - 122F |
| Product Weight | ENCLTV5055: 88.2 lbs ENCLTV5765: 124.8 lbs |
| Dimensions | ENCLTV5055: 53.9" (L) x 32" (W) x 6.9" (D) ENCLTV5765: 72.3" (L) x 42.1" (W) x 6.9" (D) |
| Power Cords (Fan) | UL Listed |



Enjoy your new protective enclosure!

CONTACT INFORMATION:

www.displays2go.com PHONE: 844-221-3388