

# QUICKSTART GUIDE


43" Touch Digital Poster








## Basic Operation

- Insert the power cord into unit and connect to outlet. Flip power switch to "I" position
- To shut down, flip power switch to "O" position, then unplug the unit. Shut down unit before disassembly.

## Navigation

Click the **App Drawer**  to show all installed applications. Toggle between running applications by clicking  on the navigation bar at the bottom of the screen. The navigation bar can be minimized by pressing . To restore the navigation bar, swipe upward from the bottom of the screen.

Pre-installed apps include:				
				
DiViEX	File Explorer	Settings	Google Chrome	Google Play Store

## Settings

### Wi-Fi Connection

1. Open Settings, and select **Network and Internet** from the list of settings.
2. Select your Wi-Fi network and enter your login credentials. Click **Okay**.

**For Ethernet Connections**, plug an ethernet cable into the ethernet (RJ45) port of the unit and connect to internet router.

### Bluetooth Connection

1. Open Settings, and select **Connected Devices**.
2. Click **Pair New Device**. Make sure your bluetooth device is in pairing mode.
3. To share files over bluetooth, enable **Wi-Fi and Bluetooth Scanning** in the Location settings.

### HDMI Connection

1. Connect PC or media player via HDMI In port.
2. Open the **HDMI In** app. The HDMI input appears on screen.



**Our dedicated rentals team is here to help!**

Have a question? Contact your Rentals Representative at 888-492-1885.


# Slideshow Settings


## Transfer Media Files

There are two ways to play media on the DiViEX slideshow app: saving files to the unit's internal memory, or playing content from a USB inserted into the USB port. (This method does not save the files to the unit.)

SUPPORTED MEDIA FILES	
IMAGE	JPG, JPEG, BMP, PNG, GIF
VIDEO	AVI, MPEG4, WMV, MKV, FLV, MP4, MOV
AUDIO	MP3


### Method 1: Save Files to Unit using File Explorer

1. Transfer files to the unit.
2. Open the **File Explorer** app. 
3. Navigate to the saved file location.
4. Click **Multi** in the top ribbon to select multiple files. Once all files are selected, click **Editor**, then click **Copy**.
5. Click **LevelUp** to return to Internal Memory, then open the folder titled 'MediaFolder'.
6. Save all media files to corresponding 'Image', 'Video', or 'Music' folders inside the 'MediaFolder' by clicking **Editor**, then **Paste**.




### Method 2: Play Media from USB

1. Insert a USB drive into your computer. Create a new folder and name it "MediaFolder".
2. Create 3 subfolders inside 'MediaFolder'. Rename them "Images"; "Videos"; "Music".
3. Copy your desired images, videos, and music to the corresponding folder.
4. Safely eject USB from computer. Insert into unit.



## Play Media with DiViEX

1. Open the DiViEX application . Media files saved in the 'MediaFolder' on the unit or USB automatically appears in the timeline.
2. In the **Setting** tab, adjust the image display time, fit of media on the screen, and the transition effects between media. Enable **Auto Play** to automatically play the slideshow when DiViEX is launched. Enable **Auto Boot** to automatically play the slideshow when the unit is powered on.
3. Click **Play** to launch the slideshow.
4. To exit the slideshow, press the **Home** button on the navigation bar.

