

Tiered Wooden Display

Assembly Instructions

SKUs: PN9BKTBLK, PN9BKTOAK, SW9BKT



DISPLAYS2GO
CONNECTING PEOPLE & BRANDS WITH THE WORLD



Parts List

A	2	Sides - 44" X 11 1/4"
B	6	1X2 Strips - 37" Long
C	9	Baskets
D	12	Bolts
E	1	Allen Wrench

No tools required except for the allen wrench that is provided.



Scan QR to visit product page

1. Attach 1x2 strip to the two side pieces, using the included bolts and the allen wrench to tighten.
NOTE: Holes at the ends of the 1x2 strips correspond to the smaller holes that are pre-drilled in the sides. Repeat for all holes on the front and back of the unit (x6 total).
2. Place baskets on the display, as shown. They will rest on the frame, angled toward the front of the unit.
3. Save the included allen wrench. Over time, the wood frame may shrink and cause the bolts to loosen. They will need to be tightened.

If you have any questions regarding our products, please visit us at www.displays2go.com or contact D2G customer service at 844-221-3388.