

XLR Audio Interface Operating Instructions

- 1. This product is equipped with a built-in 48V phantom power supply. When using the XLR interface, please turn off the 48V phantom power switch on the external audio mixer.**

Location of the 48V phantom power switch on this unit (see the arrow position in the diagram)

2. Correct operation steps for the XLR interface:
- First, turn off the 48V phantom power switch of the external audio mixer.
 - Plug in the XLR cable.
 - Plug in the microphone.
 - Turn on the built-in 48V phantom power switch of this product (refer to the arrow position in the diagram).

Note: When the XLR interface is not in use, please turn off the built-in 48V phantom power switch (refer to the arrow position in the diagram).

