

# AVLG72 TV Stand Assembly Instructions

---



Remove end caps & slide extrusion into center of the channel and back of base. Tighten with Allen key and replace end caps.



Place mount(s) onto pole(s) and tighten screws.



After sliding poles into brackets and tightening top screws, place both large brackets onto the mount.



Tighten Allen screws with Allen key on both sides.



Line up long brackets with appropriate holes on back of television and screw in with provided screws.



With assistance, lift television above poles and slide hooks onto poles firmly.



Tighten screws on back of brackets.