

INSTRUCTION SHEET



72 CLIPPER™ Display

With a 16" Base

CONTENTS:


- ✓ 1- 16" Round Base
- ✓ 1- Three Piece Pole Set
- ✓ 2- CLIPPER™ Assemblies
- ✓ 1- Support Pin
- ✓ 1- Sign Clip

5



Top with sign clip
and sign.

1




Place short (15")
pole on top

Sticker End

Insert pole into base,
sticker end down. Then
add middle and top
poles as shown.


2



Clipper Assembly


Slide first Clipper
Assembly with Clips facing
DOWN over the pole until
the bottom of the
Assembly is below the
punched hole. Insert the
support pin and rest the
top of the Assembly on
the support pin.

3



Slide second Clipper
Assembly with clips
facing down over the
pole and rest on top of
the assembly
already in place.

4



Snap open the
Assemblies as shown
and rotate until top and
bottom Assemblies line
up and lock in place.