



" In order to put the small advertising items into the clear PC pole, please screw out the belt cassette from the pole, then put items into the pole, and finally screw the belt cassette back to the pole."