

EWEASELNT1 Assembly Instructions



Tighten the wingnut to secure both leg pieces together. Repeat the same procedure with other legs.



Tighten the wingnut from the top side to hold the three poles together.



Combine the front and back bar together. Then, insert the chain and tighten the wingnut.



Your easel is ready for use!