## FDIFCROT - Inflatable Ottoman

## DISPLAYS2GO



1. Remove the packing materials. Lay out the inflatable ottoman and the printed fabric cover on a clean surface.



2. Unfold the ottoman, locate the valve.



3. Open the valve to inflate.



4. Inflate 1/2 of the air ottoman from the valve.



5. Close the 1st valve tightly. (see the image on the right)






6. Place the air ottoman inside the cover. 7. Inflate the whole air ottoman with



7. Inflate the whole air ottoman with the 2nd valve




the 2nd valve.



8. Close the 2nd valve and push it inside the ottoman cover.



9. Pull the zipper to close the cover. The assembly is finished.





If you have any questions regarding our products, please visit us at www.displays2go.com or contact D2G customer service at 844-221-3388.