


ASSEMBLY INSTRUCTIONS

GRNSCRNCCB - Collapsible Green Chair Screen

SETUP

1 Remove the folded back screen from the carrying bag and hold the steel spring firmly. Carefully pop open the screen to expand it fully.



2 Attach the green screen to the chair with the chair back inserted in between the straps and the screen.




NOTE:

1. The back screen fits most of the chairs with a vertical back.

You can attach the screen either in front of the chair back or at the back.


2. The right side has the hook and loop attachment that can be pulled open for quick and easy installation.

The left side is sewn on the screen.




FOLD AND PACK

1 Hold the edge near you and the opposite edge together firmly.



2 Grab both sides and fold inward.



3 Press 1 side down and the other side over the folded screen.



4 Press down the screen and it transforms into a disk shape.



5 Hold the steel spring and place the folded screen into the carrying bag. Zip up the bag for storage or transportation.

