




TV STANDS

ASSEMBLY INSTRUCTIONS

Diagram of the assembled TV stand with parts labeled: B1 (base plate), B2x2 (base casters), B3 (lower column), B4 (lower shelf), B5 (upper column), B6 (upper shelf), B7 (upper arm), B8x2 (upper arm bars), and B9x2 (upper arm casters).

G1x2		G2x1	G3x1
G4x1	G5x5	A1x2	A2x2
A3x4	A4x2	A5x4	A6x4
A7x4	A8x1		

