


TNMWALL10 - 10' X 10' Mesh Tent

Scan QR code to visit
the product page



STEP 1. Fully expand the mesh tent and locate the hook and loop strips on the top edge. Line up hook and loop strip with the matching piece at the bottom of the canopy and attach it firmly. Repeat the step to connect all 4 sides.

STEP 2. Find the hook and loop strip on the zipper edge and attach it to the leg pole with the buckle. Do this for the rest hook and loop strips.



STEP 3. Zip up the 2 edges that meet at the corner to close the mesh tent. The assembly is finished. Use the zipper door on one side for easy entry as shown in the middle picture.



STEP 4. Open the windors on the mesh tent as you like. You can roll up the mesh and use the string to keep it in the place.



If you have any questions regarding our products, please visit us at www.displays2go.com
or contact D2g customer service 844-221-3388.