


ASSEMBLY INSTRUCTIONS

WFCSBK3624 (Black) - 24"X36"


WFCSWH3624 (White) - 24"X36"

Indoor use **ONLY**. No tools are required for assembling.

Remove the packing and unfold to open the frame.



Adjust the leveler feet as needed.



Insert 24"X36" graphics into the frame.

Scan QR code to visit the product page:

