

NOTE: PLEASE CONFIRM ALL PARTS SHOWN OR NOTED ARE PRESENT BEFORE STARTING.

Parts List

BOX-1		
A. Base		X1
B. Pole Adapter		X1
C. Wire Collar		X2
D. Header Clip		X1

BOX-2		
E. Metal Wire Frame		X1
F. Center Pole		X2
G. Bearing Assembly (2 washers & ball bearing)		X1
H. Metal Pin		X1

Assembly Instructions


Step 1: Place the base on the floor and press the pole adapter into the center hole.



Step 2: Insert center pole with pre-drilled hole into base until completely seated (pre-drilled hole at bottom).



Step 3: Insert the metal pin into pre-drilled hole in the pole. Use a hammer as desired.




Step 4: Slide bearing assembly onto pole until it is seated on the inserted pin.




Drop (1) collar onto the bearing assembly through the pole as shown below.

Step 5: Insert the 2nd pole into the pole assembled in the base. Slide metal wire frame onto the assembled pole. Be sure the bottom collar fits into the center of the wire frame.



Step 6: Slide the 2nd collar down from the top of the pole, and fit it into the center of the wire frame. Insert header clip at the top of the pole.



The assembly is finished.



If you have any questions regarding our products, please visit us at www.displays2go.com or contact D2G customer service.