



ASSEMBLY INSTRUCTIONS

IPBOOTHWL - Wall Mounting Photo Booth

3 Install ring light to the wall mount



Setting static position



Plug in the power cable of the ring light.

Setting tilt angle position and 360° rotation

**TENSION ADJUSTMENT
AFTER WALL MOUNT INSTALLATION**

Warning

Do not adjust tension without putting on the ring light!

Adjustment sign

Anti-clockwise reduce tension
(carry less weight)

clockwise to increase tension
(carry more weight)

Step2

Step1

Caution

If the ring light is gradually sliding down, turn anti-clock using allen key to increase tension until screen stay as your wish. Likewise, turn clockwise to reduce tention.

+ : Torque increased
- : Torque reduced

Step 1

Step 2

Step 3

Please beware of unbalance ring-light gravity during ring-light installation to mount.

If you have any questions regarding our products, please visit us at www.displays2go.com or contact D2G customer service 844-221-3388.