







PODIUM

Assembly Instructions

PARTS			HARDWARE BAG							
A	Top Panel	1 pc	H1	Cam Lock	20 pcs		H4	Locking Caster	2 pcs	
B	Side Panel	2 pcs								
C	Bottom Panel	1 pc	H2	Cam Post	20 pcs		H5	Plain Caster	2 pcs	
D	Back Panel	1 pc								
E	Shelf	1 pc	H3	Wood Screw	16 pcs		H6	Adjustable Pin	4 pcs	

Attention: Before you start assembling your podium; please prepare a soft surface work area on the floor. The only tool you will need is a screwdriver. Carefully remove all hardware from packaging and place the hardware parts on the soft work area where they will not come in contact with the laminated wood lectern components. To avoid damage to the laminated wood surfaces, keep hardware parts separated until they are needed for assembly.

