Item: LDRSHLWH62,LDRSHLBR62



Left Frame X 1 & Right Frame X 1



washers X 20


Shelves X 5 D14" D12" D10" D7.5"







I Bracket X 2 Screws X 4 Plastic Anchors X2



- 1. 2.
- Attach D14" D12", D10", D9" and D7.5" shelves in slots of the left frame. Fix each shelf by fastening 2 screws and washers from side of the left frame.
- 3. Align the right frame with all shelves inside the corresponding slots. Fasten right frame to all shelves using the rest screws and washers.
- If necessary, there are additional L brackets that 4. provided for extra stability to the wall.
 - To attach L brackets use a screw to secure one side of the L bracket into the leaning clothing rack.
 - Drill hole into the wall and insert plastic b. anchor into the wall.
 - Use the other screw to fasten the other C. side of the L bracket into the plastic anchor in the wall.
 - Repeat for other side frame d.



NOTE:

- 1. Be sure the whole rack is tightly assembled.
- 2. The rack may loosen overtime. Check that all connections are tight periodically.