



4. Adjustment



Push or pull from the top or bottom of the screen to obtain the desired angle.

5. Install curved TV




NOTE: To install curved TV, please use "M8*30 screw+big spacer(15mm) or big&small(20mm) Spacer together"

NOTE: To install curved TV, please use "M8*50 screw+big&big spacer(30mm) or big&big&small spacer(35mm) or big&big&small&small(40mm) Spacer together"

M8x30MM Screw+ M8x15MM Spacer or M8x20MM Spacer


M8x50MM Screw+ M8x30MM Spacer or M8x35MM Spacer or M8x40MM Spacer



Maintenance

- Check that the bracket is secure and safe to use at regular intervals(at least every three months).
- Please contact your dealer if you have any questions.

Tilting Wall Mount



CAUTION: DO NOT EXCEED RATED LISTED WEIGHT CAPACITY. SERIOUS INJURY OR PROPERTY DAMAGE MAY OCCUR!



200x200/300x300
400x200/400x400




NOTE: Read the entire instruction manual before you start installation and assembly.

⚠ WARNING


- Do not begin the installation until you have read and understood the instructions and warnings contained in this installation sheet. If you have any question regarding any of the instructions or warnings, please contact your local distributor.
- This mounting bracket was designed to be installed and utilised **ONLY** as specified in this manual. Improper installation of this product may cause damage or serious injury.
- This product should only be installed by someone with good mechanical ability who has basic building experience and fully understands this manual.
- Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.
- If mounting to wood wall studs, make sure that mounting screws are anchored into the center of the studs. The use of a stud finder is highly recommended.
- Always use an assistant or mechanical lifting equipment to safely lift and position the equipment.
- Tighten screws firmly, but do not over tighten. Over tightening can cause damage to the items, This greatly reduces their holding power.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

Component Checklist


IMPORTANT: Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, telephone your local distributor for a replacement.





Package M




Package W





1a. Wood Stud Wall Mounting





Find and mark the exact location of mounting holes



Drill pilot holes



Screw the wall plate onto the wall






Stud	406mm (16")	450mm (17.7")	600mm (23.6")	610mm (24")
	✓	X	X	X


! WARNING

- Make sure that mounting screws are anchored into the center of the studs. The use of a stud finder is highly recommended.
- Installers are responsible to provide hardware for other types of mounting situations.
- Installers must verify that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.



1b. Solid Brick and Concrete Mounting





Mark the exact location of mounting holes



Drill pilot holes




Screw the wall plate onto the wall




! WARNING

Installers must verify that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.





2. Installing the Adapter Brackets



2-1 For Flat Back Screen



2-2 For Recessed Back Screen or to Access A/V Inputs




Note: Choose appropriate screws, washers and spacers (if necessary) according to the type of screen.

- Position the adapter brackets as close as possible to the center of the TV.
- Screw the adapter brackets onto the TV.

⚠ Tighten all screws but do not over tighten.

3. Hang the TV onto the Wall Plate



- Turn the lock plate downward to lock the wall plate.
- Use the padlock to prevent the TV from being stolen (The padlock is not included).